



APPLICATION INSTRUCTIONS

MY DECK PROJECT



FLOOD® CWF-UV5

Ideal for newer wood, Flood CWF-UV5 is a premium product that adds minimal color and highlights the natural wood grain. Its penetrating formula is long-lasting, offering superior sun and rain protection. See the product label for more information and details regarding application.

1. Cover everything you do not wish to coat, including plants.
2. Make sure the wood surface has been properly prepared and is completely dry. (See flood.com/guideme for help choosing the right prep product based on the type and condition of the wood.)
3. For color uniformity, intermix all containers being used, and do not thin the product.
4. Stir the finish before and periodically during application.
5. Test the color, if applicable, in a small area.
6. Apply an even coat with a synthetic brush, roller or airless sprayer, avoiding heavy application.
7. After spray application, backbrush or backroll to improve penetration and uniformity of coverage. Remember, Flood CWF-UV5 is not a surface coating. It protects by penetrating the wood surface.
8. For porous or older wood, if required, apply a second coat before the first coat has dried (within 20 minutes).
9. Allow surfaces to dry for 24 to 48 hours.

APPLICATION OPTIONS

- Synthetic brush
- Roller
- Airless sprayer

WEATHER REQUIREMENTS

- Apply CWF-UV5 in temperatures between 50° and 90° F.
- Do not apply CWF-UV5 if cold and/or wet weather is expected within 24 hours.

APPLICATION TIPS

- To avoid lap marks, always work the entire length of a board while maintaining a wet edge. Never stop application in the middle of the board.
- Vertical surfaces should be coated from top to bottom.

CLEANUP

- Clean tools with soap and water.

IMPORTANT NOTES

- Wear safety glasses.
- Do not apply CWF-UV5 in direct sunlight or on hot surfaces.
- CWF-UV5 is for exterior use only; do not use it indoors.