

Application:

- Remove the top lid to expose scratch surface on cap
- Twist and remove cap to expose black button on Chimfex
- Hold away from face and activate by lightly scratching black button with surface of cap
- Immediately drop alongside the fire, not directly in the fire
- For Fireplaces: Close doors or cover opening with non flammable material. For Wood Stoves: Close doors and all intake vents
- Chimfex smoke emissions rise up the flue to replace the oxygen in a few seconds
- Due to internal differences in chimneys and wood burning stoves, some large flues may require two or more units activated simultaneously to suppress the fire

Storage/Handling:

Always point Chimfex away from face and body while activating and afterward. Acquaint your household with use instructions and directions to insure proper and safe handling and use of Chimfex. Store in a cool, dry place. For disposal: Open burning is preferred method of disposal in compliance with appropriate federal, state and local regulations.

Cautions:

Flammable. Harmful if swallowed. Irritant to eyes, skin and respiratory tract. If swallowed, consult a physician immediately. If eye contact occurs, flush with water for 15 minutes. Consult a physician.
KEEP OUT OF REACH OF CHILDREN