


# LED AREA LIGHT

---

## IMPORTANT SAFETY INSTRUCTIONS AND INSTALLATION GUIDE



**READ BEFORE INSTALLATION**  
**SAVE THESE INSTRUCTIONS**

Questions, problems, missing parts? Before returning to the store,  
call Feit Electric Customer Service  
8 a.m. - 5 p.m., PST, Monday - Friday

1-866-326-BULB (2852)

[FEIT.COM](http://FEIT.COM)

# Table of Contents

Table of Contents .....	2
Safety Information .....	2
FCC Statement .....	2
Warranty .....	2
Pre-Installation .....	3
Pole Mount Installation .....	4
Wall Mount Installation .....	4
Care and Maintenance .....	5
Troubleshooting .....	5

## Safety Information

### READ BEFORE INSTALLATION

1. Follow all safeguards stated in the manual, in addition to normal safety precautions in working with electrical devices. Always follow basic safety precautions to reduce the risk of fire, electric shock and personal injury.
2. **WARNING: RISK OF SHOCK:** House electric current can cause painful shock or serious injury unless handled properly. For your safety, always remember to:
  - A. Turn OFF the power supply at the fuse or circuit breaker box before you install the fixture.
  - B. Ground the fixture to avoid potential electric shock and to ensure reliable starting.
  - C. Double check all connections to be sure they are tight and correct.
  - D. Wear Rubber sole shoes and work on a sturdy ladder.
3. This fixture is designed for use in a circuit protected by a fuse or circuit breaker. It is also designed to be installed in accordance with local electrical codes. If you are unsure about your wiring, consult a qualified electrician or local electrical inspector, and check your local electrical code.
4. **WARNING: RISK OF CUTS:** Some metal parts in the fixture may have sharp edges. To prevent cuts and scrapes, wear gloves when handling the parts.
5. Account for small parts and destroy packaging material, as these may be hazardous to children.



**WARNING:** These products may represent a possible shock or fire hazard if improperly installed or attached in any way. Products should be installed in accordance with the owners manual, current electrical codes and/or the current National Electric Code (NEC). Properly ground electrical enclosure. Use only UL or IEC approved wire for input/output connections.



**WARNING:** Risk of fire. Use only on 120 volt 60Hz circuits. Suitable for wet locations. Do not use with dimmers. Do not look directly at the operating LED lamp. The luminaire should be grounded. This device is not intended for use with emergency exits or emergency lights.



**CAUTION:** To avoid risk of fire, explosion, or electrical shock, this product should be installed, inspected and maintained by a qualified electrician only, in accordance with all applicable electrical codes. Be certain electrical power is OFF before and during installation and maintenance.

### SAVE THESE INSTRUCTIONS

#### FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. Any changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment. CAN ICES-005 (B)


**Supplier's Declaration of Conformity:**  
47 CFR § 2.1077 Compliance Information

**Responsible Party:**  
Feit Electric Company  
4901 Gregg Road,  
Pico Rivera, CA 90660, USA  
562-463-2852

**Unique Identifier:**  
S13AREA/850/DD/SS/V1

### Limited Warranty


This product is warrantied to be free from defects in workmanship and materials for up to 5 years from date of purchase. If the product fails within the warranty period, please contact Feit Electric at [info@feit.com](mailto:info@feit.com), visit [feit.com/contact-us](http://feit.com/contact-us) or call 1-866-326-BULB (2852) for instructions on replacement or refund. REPLACEMENT OR REFUND IS YOUR SOLE REMEDY. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTIES ARE LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY. LIABILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES IS HEREBY EXPRESSLY EXCLUDED. Some states and provinces do not allow the exclusion of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state or province to province.




## HARDWARE INCLUDED



**NOTE:** Hardware not shown to actual size.



AA



BB



CC




DD


Part	Description	Quantity
AA	Area Light Fixture	1
BB	Mounting Screws	3
CC	Screw Anchors	3
DD	Wire Connectors	3

# Pole Mount Installation

**1** Turn the power OFF at the switch and fusebox or the circuit breaker.

**2** Use the Wire Connectors (DD) to connect the wires: Green to Ground, Neutral to White and Hot to Black.

 **NOTE:** Fits 1.5 in. Diameter mounting pole.



**3**  Feed the power supply wires through the Mounting Pole.



Install the Area Light Fixture (AA) into the pole, then tighten the screws on the Area Light Fixture (AA) into the mounting pole.




**4** Once the fixture is tightly secured to J-Box, apply silicone sealant around the base of the fixture to prevent moisture from reaching the connections.

# Wall Mount Installation


**1** Remove the grommet and install the conduit fitting (not included). Feed your wires through the conduit.



**2** Place the Area Light Fixture (AA) end onto the wall at the desired location and mark the position for the Mounting Screws (BB). Drill 3 holes as required using a 3/16 in. drill bit, either for the pilot holes for the Mounting Screws (BB) or holes for the Screw Anchors (CC). Install the Screw Anchors (CC) as appropriate.



**3** Feed the power supply wires into the conduit fitting and connect with Area Light Fixture (AA) wires; Ground to Ground, Neutral to White and Hot to Black. Mount the Area Light Fixture (AA) housing to the wall as appropriate.



**4** Once the fixture is tightly secured to J-Box, apply silicone sealant around the base of the fixture to prevent moisture from reaching the connections.

---

## CARE AND MAINTENANCE

Periodically clean the fixture and diffuser using a mild, non-abrasive cleaner and soft cloth. When cleaning the fixture, make sure the power is turned off. Do not spray cleaner directly onto any part of the fixture or LEDs.

## TROUBLESHOOTING

Extreme hot or cold weather could affect the performance of the built-in sensors that detect body heat.


Certain winter clothing can shield a person's body heat from the sensor during extreme cold weather.

During extreme hot weather, the sensor may not be able to distinguish the difference between normal body temperatures and the surrounding high temperatures. The sensor will begin working normally once weather conditions return to normal.

PROBLEM	POSSIBLE CAUSE	CORRECTIVE ACTION
LED Area Light comes on during the day.	<ol style="list-style-type: none"><li>1. Dusk-to-Dawn sensor is in a shaded area and is fooled into thinking it is nighttime.</li><li>2. Dusk-to-Dawn sensor is faulty.</li></ol>	<ol style="list-style-type: none"><li>1. Shine a flashlight onto the light sensor. If the security light turns off then the fixture is mounted in an area that does not allow enough light to enter the sensor. Relocate LED Area Light.</li><li>2. If under warranty, contact Customer Service.</li></ol>
LED Area Light cycles ON and OFF continuously	<ol style="list-style-type: none"><li>1. Dusk-to-Dawn sensor is sensing reflected light from the LED Area Light.</li></ol>	<ol style="list-style-type: none"><li>1. Put a small piece of black electrical tape over the Dusk-to-Dawn sensor.</li><li>2. Relocate the LED Area Light to a different location where it no longer causes reflected light.</li></ol>

# LUMIÈRE DE ZONE

## INSTRUCTIONS DE SÉCURITÉ IMPORTANTES ET GUIDE D'INSTALLATION



**LIRE AVANT L'INSTALLATION**  
**CONSERVEZ CES INSTRUCTIONS**

Questions, problèmes, pièces manquantes? Avant de retourner au magasin,  
appelez le service client de Feit Electric  
De 8 h à 17 h, heure du Pacifique, du lundi au vendredi

1-866-326-BULB (2852)

[FEIT.COM](http://FEIT.COM)

Table des matières .....	7
Information sur la sécurité.....	7
Déclaration FCC.....	7
Garantie.....	7
Pré-installation.....	8
Installation sur poteau .....	9
Installation murale .....	9
Entretien et maintenance .....	10
Dépannage.....	10

## Information sur la sécurité

### LIRE AVANT L'INSTALLATION

- Suivez toutes les mesures de sécurité indiquées dans le manuel, en plus des précautions de sécurité normales lorsque vous travaillez avec des appareils électriques. Respectez toujours les précautions de sécurité de base pour réduire les risques d'incendie, d'électrocution et de blessures.
- AVERTISSEMENT: RISQUE DE CHOC:** Le courant électrique de la maison peut provoquer un choc douloureux ou des blessures graves s'il n'est pas correctement remis. Pour votre sécurité, n'oubliez pas de:
  - Coupez l'alimentation électrique au niveau de la boîte à fusibles ou du disjoncteur avant d'installer l'appareil.
  - Mettez l'appareil à la terre pour éviter tout risque d'électrocution et pour garantir un démarrage fiable.
  - Vérifiez toutes les connexions pour vous assurer qu'elles sont bien serrées et correctes.
  - Portez des chaussures à semelle en caoutchouc et travaillez sur une échelle solide.
- Cet appareil est conçu pour être utilisé dans un circuit protégé par un fusible ou un disjoncteur. Il est également conçu pour être installé conformément aux codes électriques locaux. Si vous n'êtes pas sûr de votre câblage, consultez un électricien qualifié ou un inspecteur électrique local et vérifiez votre code électrique local.
- AVERTISSEMENT: RISQUE DE COUPURES:** Certaines pièces métalliques de l'appareil peuvent avoir des arêtes vives. Pour éviter les coupures et les éraflures, portez des gants lors de la manipulation des pièces.
- Tenez compte des petites pièces et détruisez les matériaux d'emballage, car ils peuvent être dangereux pour les enfants.



**WARNING:** These products may represent a possible shock or fire hazard if improperly installed or attached in any way. Products should be installed in accordance with the owners manual, current electrical codes and/or the current National Electric Code (NEC). Properly ground electrical enclosure. Use only UL or IEC approved wire for input/output connections.



**WARNING:** Risk of fire. Use only on 120 volt 60Hz circuits. Suitable for wet locations. Do not use with dimmers. Do not look directly at the operating LED lamp. The luminaire should be grounded. This device is not intended for use with emergency exits or emergency lights.



**CAUTION:** To avoid risk of fire, explosion, or electrical shock, this product should be installed, inspected and maintained by a qualified electrician only, in accordance with all applicable electrical codes. Be certain electrical power is OFF before and during installation and maintenance.

### CONSERVEZ CES INSTRUCTIONS DÉCLARATION FCC

Ce dispositif est conforme à la partie 15 des règles de la FCC. Le fonctionnement est soumis aux deux conditions suivantes, cet appareil : 1) ne doit pas causer d'interférences nuisibles, 2) doit accepter toutes les interférences reçues, y compris celles susceptibles de provoquer des interférences nuisibles. Remarque : Cet équipement a été testé et répond aux limites établies pour les appareils numériques de catégorie B, conformément à la partie 15 des règles de la FCC. Ces limites sont établies afin d'offrir une protection raisonnable contre toute interférence nuisible dans une installation résidentielle. Cet équipement génère, utilise et émet de l'énergie radioélectrique et peut causer des interférences nuisibles dans les communications radio s'il n'est pas correctement installé et utilisé. Toutefois, rien ne garantit qu'aucune interférence ne se produira dans une installation donnée. Si cet équipement cause des interférences nuisibles aux communications radiophoniques ou télévisuelles, lesquelles peuvent être repérées en allumant et en éteignant l'équipement, l'utilisateur peut essayer de remédier au problème par l'une des mesures suivantes : réorienter ou déplacer l'antenne réceptrice. Augmenter la distance entre l'équipement et le récepteur. Brancher l'équipement dans une prise qui ne se trouve pas sur le même circuit que celui dans lequel le récepteur est connecté. Consulter le fournisseur ou un technicien radio/TV expérimenté pour obtenir de l'aide. Tout changement ou modification non expressément approuvé par le fabricant pourrait annuler le droit de l'utilisateur à utiliser l'équipement. CAN NMB-005 (B).

#### Déclaration de conformité du fournisseur:

47 CFR § 2.1077 Informations de conformité

#### Partie responsable:


Feit Electric Company  
4901 Gregg Road,  
Pico Rivera, CA 90660, USA  
562-463-2852

#### Identifiant unique:

S13AREA/850/DD/SS/V1

### Garantie Limitée

Ce produit est garanti d'être exempt de défauts de fabrication et de matériaux pendant 5 ans maximum à compter de la date d'achat. Si le produit échoue pendant la période de garantie, veuillez contacter Feit Electric à [info@feit.com](mailto:info@feit.com), visiter [feit.com](http://feit.com) ou appeler les services à la clientèle 1-866-326-BULB (2852) pour obtenir des instructions sur le remplacement ou le remboursement. LE REMPLACEMENT OU LE REMBOURSEMENT EST VOTRE SEUL RECOURS. SAUF DANS LA MESURE INTERDITE PAR LA LOI APPLICABLE, TOUTES GARANTIES IMPLICITES SONT LIMITÉES A UNE PERIODE À LA DURÉE DE CETTE GARANTIE. LA RESPONSABILITÉ POUR LES DOMMAGES ACCESSOIRES OU INDIRECTS EST EXPRESSÉMENT EXCLUE. Certains états et provinces n'autorisant pas l'exclusion de dommages consécutifs ou indirects, ainsi la limitation ou l'exclusion ci-dessus peut ne pas s'appliquer à vous. Cette garantie vous donne des droits légaux spécifiques et vous pouvez également avoir d'autres droits qui varient d'un état à l'autre ou d'une province à l'autre.



## MATÉRIEL INCLUS



**REMARQUE:** Matériel non présenté à sa taille réelle.




AA



BB



CC



DD


Partie	La description	Quantité
AA	Luminaire de zone	1
BB	Vis de montage	3
CC	Ancres à vis	3
DD	Connecteurs de fil	3



**1** Coupez l'alimentation au niveau de l'interrupteur et de la boîte à fusibles ou du disjoncteur.

**2** Utilisez les connecteurs de fils (DD) pour connecter les fils: vert à la terre, neutre au blanc et chaud au noir.

**REMARQUE:** Convient au poteau de montage de 1,5 po de diamètre.





**3**  Faites passer les fils d'alimentation à travers le poteau de montage.

Installez le luminaire de zone (AA) dans le poteau, puis serrez les vis du luminaire de zone (AA) dans le poteau de montage.




**4** Una vez que el accesorio esté bien asegurado a J-Box, aplique sellador de silicona alrededor de la base del accesorio para evitar que la humedad llegue a las conexiones.


**1** Retirez le passe-fil et installez le raccord de conduit (non inclus). Faites passer vos fils dans le conduit.



**2** Placez l'extrémité du luminaire (AA) sur le mur à l'emplacement souhaité et marquez la position des vis de montage (BB). Percez 3 trous au besoin à l'aide d'un foret de 3/16 po, soit pour les trous pilotes pour les vis de montage (BB), soit pour les trous d'ancrage pour vis (CC). Installez les vis d'ancrage (CC) comme il convient.



**3** Faites passer les fils d'alimentation dans le raccord de conduit et connectez les fils du luminaire de zone (AA); Terre à terre, neutre à blanc et chaud à noir. Montez le boîtier du luminaire de zone (AA) sur le mur, le cas échéant.



**4** Una vez que el accesorio esté bien asegurado a J-Box, aplique sellador de silicona alrededor de la base del accesorio para evitar que la humedad llegue a las conexiones.

## SOIN ET MAINTENANCE

Nettoyez régulièrement le luminaire et le diffuseur à l'aide d'un nettoyeur doux et non abrasif et d'un chiffon doux. Lors du nettoyage de l'appareil, assurez-vous que l'alimentation est coupée. Ne vaporisez pas de nettoyeur directement sur une partie de l'appareil ou des LED.

## DÉPANNAGE

Un temps extrêmement chaud ou froid pourrait affecter les performances des capteurs intégrés qui détectent la chaleur corporelle. Certains vêtements d'hiver peuvent protéger la chaleur corporelle d'une personne du capteur par temps extrêmement froid. Par temps extrêmement chaud, le capteur peut ne pas être en mesure de distinguer la différence entre les températures corporelles normales et les températures élevées environnantes. Le capteur commencera à fonctionner normalement une fois que les conditions météorologiques reviendront à la normale.

PROBLÈME	CAUSE POSSIBLE	ACTION CORRECTIVE
La lumière de zone LED s'allume pendant la journée.	<ol style="list-style-type: none"><li>1. Le capteur Dusk-to-Dawn se trouve dans une zone ombragée et est dupé en pensant qu'il fait nuit.</li><li>2. Le capteur Dusk-to-Dawn est défectueux.</li></ol>	<ol style="list-style-type: none"><li>1. Faites briller une lampe de poche sur le capteur de lumière. Si le voyant de sécurité s'éteint, le luminaire est monté dans une zone qui ne permet pas à suffisamment de lumière de pénétrer dans le capteur. Déplacer la lumière de zone LED.</li><li>2. Si sous garantie, contactez le service client.</li></ol>
L'éclairage de la zone LED s'allume et s'éteint en continu	<ol style="list-style-type: none"><li>1. Le capteur Crépuscule à l'aube détecte la lumière réfléchi par la lumière LED.</li></ol>	<ol style="list-style-type: none"><li>1. Mettez un petit morceau de ruban électrique noir sur le capteur Crépuscule à l'aube.</li><li>2. Déplacez la LED Area Light vers un autre emplacement où elle ne produit plus de lumière réfléchi.</li></ol>