

contigo®



AUTOSPOUT® Water Bottle
Care and Use Instructions

⚠ CAUTION

- Product is NOT designed for hot liquids. Use only with cold liquids.
- Not for use with carbonated or pulpy beverages.
- Prior to drinking, make sure the lid is properly threaded to the body and screwed on completely.
- Avoid accidental depressing of the AUTOSPOUT™ button by keeping the button free and clear of other objects.
- DO NOT overfill. Fill liquids to just below the threading in the body.
- DO NOT microwave or freeze.
- DO NOT use cleaners containing bleach, chlorine, abrasives and/or other harsh chemicals.
- DO NOT continue to use product if damaged.
- DO NOT carry bottles containing liquid in bags to help prevent accidental opening.

USAGE RECOMMENDATIONS:

TO OPEN





TO CLOSE





- Do not pull or rotate the spout shield as it may cause damage to the lid.
- Silicone drink spout is NOT removable.
- When using the water bottle at high altitudes, such as during an airplane flight or when bottle is exposed to prolonged hot temperatures, such as in an enclosed car, twist the lid a quarter turn to relieve pressure, then reseal the lid before use.
- The AUTOSPOUT™ lid that came with your new purchase is designed to only fit your Contigo® water bottle. Not for use with other products.

CLEANING INSTRUCTIONS

- Wash thoroughly before first use.
- RINSE IMMEDIATELY AFTER EACH USE with warm water and spout in the open position.
 - Remove straw for best results.
- Lid, plastic body and straw are top-rack dishwasher safe.



- If washing by hand, soak lid for 10 minutes in hot, soapy water. Hand wash body with warm water and a mild detergent. Rinse both lid and body thoroughly before use.
- For best cleaning results, use a Contigo® bottle + spout brush, www.GoContigo.com.



- ALWAYS STORE BOTTLE WITH LID REMOVED to allow parts to dry completely.



©2014 Ignite USA. All Rights Reserved.

Should you have any questions about your purchase, please contact us at 1-888-262-0622