

Care Instructions

SILPAT® is designed for every type of oven. From savory to pastry baking, SILPAT® will provide even heat transfer to your baked goods.

HOW TO USE:

1. Rinse before first use.
2. Place SILPAT® on a sheet pan with writing facing up.
3. Lay product to be baked or frozen on SILPAT®.
4. Baking temperatures may need to be adjusted according to your oven. SILPAT® is effective in temperatures from -40°F to 480°F or -40°C to 280°C.
5. No greasing required.
6. Store flat or rolled.

EASY TO CLEAN!

- Wipe the SILPAT® with a damp, soft sponge, then rinse with clean water.
- Shake to remove excess water and dry in open air.
- A weak solution of detergent or soap may be used if needed.
- **Note:** the oily feeling after washing is normal, as is discoloration. Strong flavored foods may leave a trace of their scent on the SILPAT®.